
DISASSEMBLY 77

- Needle Bearing
 Balancer Shaft
- 3. Washer
- 4. Splined Washer
- 5. Circlip
- 6. Washer 7 Sprocket

- 8. Pin 9. Spring
- 10. Balancer Weight
- 11. Balancer Chain
- 12. Lock Washer
- 13. Bolt 14. Chain Guide
- 15. Cotter Pin 16. Tensioner Body
- 17. Pin
- 18. Chain Guide
- 19. Lock Washer
- 20. Bolt
- 21. Spring
- 22. Tensioner Pin



balancer

unit):

•With the springs and pins (4 ea) all in the inner place in circumference of the balancer weight, install the sprocket. The punch mark on the sprocket must face in (balancer weight side), with the sprocket positioned as depicted in Fig. 274. Only one οf four positions is correct, and that is with punch mark opposite the weight.





- Put on the washer and circlip. Use a new circlip if it is deformed or otherwise damaged during removal.
- •Move each spring to the furthest point outward in its space so that the springs will not hinder insertion of the balancer shaft through the weight.

Balancer Chain Tensioner Disassembly:

- •Remove the cotter pin 15, pull out the pin 17, and remove the chain guide 18.
- •Pull out the tensioner pin 22, spring 21.

Balancer Chain Tensioner Assembly Note:

•Insert a new cotter pin through the pin after assembling the chain tensioner assembly, and spread out its ends.

CRANKSHAFT (Including connecting rods), CAMSHAFT CHAIN, AND

ARY CHAIN

Removal:

- •Remove the engine (Pg. 23).
- •Set the engine on a clean surface or, preferably, into
- a disassembly apparatus with some means of holding
- the engine steady while parts are being removed.

NOTE: If the engine is to be set onto the Kawasaki

engine disassembly apparatus, the one of the upper

crankcase half bolts (3) shown in Fig. 208 must be

removed before positioning the engine.
•Remove the camshafts as explained in camshaft removal

(Pg. 37).

- •Remove the cylinder block (Pg. 43).
- •Remove the pistons (Pg. 44).
- •Remove the transmission (Pg. 60).
- •Lift off the crankshaft with the camshaft chain and primary chain.