


dust seal 13 on the outside of the tube keeps dirt and water from entering and damaging the oil seal and tube surface.

Front Spring Force



- 1. Top Bolt
- 2. O Ring
- 3. Upper Clamp Bolt
- 4. Ring Cap
- 5. Fork Cover
- 6. Steering Stem
- 7. Grease Seal
- 8. Spring
- 9. Damper Ring
- 10. Damper
- 11. Stem Base Cover
- 12. Inner Tube
- 13. Dust Seal
- 14. Clip
- 15. Oil Seal
- 16. Outer Tube
- 17. Piston
- 18. Piston Ring
- 19. Circlip
- 20. Cylinder
- 21. Spring
- 22. Spring Seat
- 23. Spring
- 24. Non-return Valve
- 25. Collar
- 26. Circlip
- 27. Cylinder Base
- 28. Gasket
- 29. Alien Bolt

